

PNEUMATIC VIBRATOR COMPONENT SELECTION GUIDE

BV SERIES PISTON VIBRATORS

MODEL	T-SLOT	CHANNEL	NPT	AIRHOSE	LUBROUNIT	LEVERVALVE	SOLENOID
IMP, OI, AC, OR SI	MTG ASSY FOR FLAT SURFACES	MTG ASSY FOR CURVED SURFACES		5/6" OA WITH SWIVEL-FITTINGS	FILTER-LUBRICATOR-REGULATOR	MANUAL ON/OFF VALVE	110 VOLT/NEMA 4 NORMALLY CLOSED
BV-112	-	841-008	1/4"	972-013	971-004	972-030	972-068
BV-150	841-055	841-009	1/4"	972-013	971-004	972-030	972-068
BV-175	841-057	841-010	1/4"	972-013	971-004	972-030	972-068
BV-225	841-057	841-010	1/4"	972-013	971-004	972-030	972-068
BV-225 LONG	841-057	841-010	1/4"	972-013	971-004	972-030	972-068
BV-312	841-058	841-011	3/8"	972-016	971-007	972-032	972-070
BV-350	841-058	841-011	3/8"	972-016	971-007	972-032	972-070
BV-350 LONG	841-058	841-011	3/8"	972-016	971-007	972-032	972-070
BV-425	841-059	841-012	1/2"	972-012	971-003	972-029	972-067
BV-650	841-060	841-013	1/2"	972-012	971-003	972-029	972-067
BV-825	-	841-014	3/4"*	972-011	971-006	972-031	972-069

H SERIES BALL VIBRATORS

MODEL	MOUNTING SIZE	CHANNEL	NPT	AIRHOSE	LUBROUNIT	LEVERVALVE	SOLENOID
				5/6" OA WITH SWIVEL-FITTINGS	FILTER-LUBRICATOR-REGULATOR	MANUAL ON/OFF VALVE	110 VOLT/NEMA 4 NORMALLY CLOSED
HB-10	-	-	1/8"*	972-013	971-004	972-030	972-068
HB-19	-	-	1/4"	972-013	971-004	972-030	972-068
HC-19	C2	841-C20	1/4"	972-013	971-004	972-030	972-068
HC-25	C2	841-C20	1/4"	972-013	971-004	972-030	972-068
HC-35	C2	841-C20	1/4"	972-013	971-004	972-030	972-068
HC-41	C4	841-C40	3/8"	972-016	971-007	972-032	972-070
HC-51	C2	841-C40	3/8"	972-016	971-007	972-032	972-070
HU-13	C2	841-C20	1/8"*	972-013	971-004	972-030	972-068
HU-19	C2	841-C20	1/4"	972-013	971-004	972-030	972-068
HU-25	C3	841-C20	1/4"	972-013	971-004	972-030	972-068

SK SERIES BALL VIBRATORS

MODEL	MOUNTING SIZE	CHANNEL	NPT	AIRHOSE	LUBROUNIT	LEVERVALVE	SOLENOID
				5/6" OA WITH SWIVEL-FITTINGS	FILTER-LUBRICATOR-REGULATOR	MANUAL ON/OFF VALVE	110 VOLT/NEMA 4 NORMALLY CLOSED
SK-10	C2	841-C20	1/8"*	972-013	971-004	972-030	972-068
SK-13	C2	841-C20	1/8"*	972-013	971-004	972-030	972-068
SK-19	C2	841-C20	1/4"	972-013	971-004	972-030	972-068
SK-25	C3	841-C30	1/4"	972-013	971-004	972-030	972-068
SK-35	C3	841-C30	1/4"	972-013	971-004	972-030	972-068
SK-41	C4	841-C40	3/8"	972-016	971-007	972-032	972-070
SK-51	C4	841-C40	3/8"	972-016	971-007	972-032	972-070

HVT SERIES TURBINE VIBRATORS

MODEL	MOUNTING SIZE	CHANNEL	NPT	AIRHOSE	PIGGYBACK	LEVERVALVE	SOLENOID
				5/6" OA WITH SWIVEL-FITTINGS	FILTER-REGULATOR	MANUAL ON/OFF VALVE	110 VOLT/NEMA 4 NORMALLY CLOSED
HVT-150	C1	841-C10	1/8"*	972-013	971-008	972-030	972-068
HVT-280	C2	841-C20	1/4"	972-013	971-008	972-030	972-068
HVT-320	C3	841-C30	3/8"	972-016	971-009	972-032	972-070

GT SERIES TURBINE VIBRATORS

MODEL	MOUNTING SIZE	CHANNEL	NPT	AIRHOSE	PIGGYBACK	LEVERVALVE	SOLENOID
				5/6" OA WITH SWIVEL-FITTINGS	FILTER-REGULATOR	MANUAL ON/OFF VALVE	110 VOLT/NEMA 4 NORMALLY CLOSED
GT-8	C1	841-C10	1/8"*	972-013	971-008	972-030	972-068
GT-10	C1	841-C10	1/8"*	972-013	971-008	972-030	972-068
GT-13	C2	841-C20	1/4"	972-013	971-008	972-030	972-068
GT-16	C2	841-C20	1/4"	972-013	971-008	972-030	972-068
GT-20	C2	841-C20	1/4"	972-013	971-008	972-030	972-068
GT-25	C2	841-C20	1/4"	972-013	971-008	972-030	972-068
GT-30	C3	841-C30	3/8"	972-016	971-009	972-032	972-070
GT-36	C3	841-C30	3/8"	972-016	971-009	972-032	972-070
GT-40	C3	841-C30	3/8"	972-016	971-009	972-032	972-070
GT-48	C3	841-C30	3/8"	972-016	971-009	972-032	972-070

For assistance with choosing components for multiple vibrator systems, contact Houston Vibrator:
 PH: 800.320.4044 or 713.939.0404/E-mail: sales@houstonvibrator.com