

APPENDIX B: TROUBLESHOOTING

VIBRATOR WON'T START



AMP DRAW IS TOO HIGH



VIBRATOR MAKES POUNDING NOISE

